

Quick Reference Guide

TO YOUR NEW AUSTIN ENERGY® THERMOSTAT




Quick Settings

To Temporarily Raise Or Lower Temperature

Use the up or down arrow (① or ②) to the right of the display until the desired temperature is displayed. This will hold the temperature until your next programmed time.

To Hold The Temperature Indefinitely

With the SYSTEM (⑧) button set to heat or cool, press the HOLD button (⑥) once. Use the up or down arrow (① or ②) until the desired temperature is displayed. **Use this button only when you leave for extended periods of time. CAUTION: Using the HOLD button to maintain a temperature that is not recommended may cause your HVAC system to run excessively, resulting in high utility bills. (We recommend 78 degrees or higher in the summer and 68 degrees or lower in the winter.)**



To Release A Temperature Hold

Press the RUN (⑤) button.

To Reset The Filter Reminder

Every 150 hours (equivalent to 30 days), the filter indicator will come on to remind you to change your filter. This is the length of time recommended for a standard filter change. To clear and reset the filter reminder, press the HOLD (⑥) button and the RUN (⑤) button at the same time. This will reset the filter reminder for another 30 days.

To Operate Your Thermostat

Press the SYSTEM (⑧) button until your choice of "COOL", "HEAT", "HEAT/COOL" or "OFF" appears in the middle of the display. "HEAT/COOL" combines your heating and cooling schedules to maintain a specific temperature. The thermostat will automatically switch from cooling to heating to maintain a comfortable setting. This is a good choice when the weather is unpredictable. **Note: When "HEAT/COOL" is selected, the "HEAT" setting for every programming time must be at least 3 degrees below the "COOL" setting for the thermostat to work properly. For example, to set 74 degrees in the "COOL" program, the setting for "HEAT" has to be 71 degrees or lower.**

Programming Your Thermostat

The chart to the right shows the factory settings for this thermostat. They were recommended by ENERGY STAR®. To select these settings, simply push the RUN (⑤) button.

To program your own settings, use the blank chart on the back to determine your own times and temperatures. Keep this chart as a reference.

Time Segments

Program your thermostat with your household schedule in mind. The first time period, "MOR" may be the time you are waking up (or the first cooling/heating setting of the day). "DAY" could be the time you leave for the day so use a temperature setting that will save you money on your utility bill. "EVE" may be the time you return home at the

Factory Program
Temperatures Recommended by ENERGY STAR®
Cooling & Heating Schedule

PERIOD	WEEKDAYS (5-DAY)		SATURDAY (1-DAY)		SUNDAY (1-DAY)		
	Start Time	Temp	Start Time	Temp	Start Time	Temp	
COOL	MOR	6:00 am	78F	6:00 am	78F	6:00 am	78F
	DAY	8:00 am	85F	8:00 am	85F	8:00 am	85F
	EVE	5:00 pm	78F	5:00 pm	78F	5:00 pm	78F
	NHT	10:00 pm	82F	10:00 pm	82F	10:00 pm	82F
HEAT	MOR	6:00 am	70F	6:00 am	70F	6:00 am	70F
	DAY	8:00 am	62F	8:00 am	62F	8:00 am	62F
	EVE	5:00 pm	70F	5:00 pm	70F	5:00 pm	70F
	NHT	10:00 pm	62F	10:00 pm	62F	10:00 pm	62F

Used properly, this thermostat can save 10% - 20% on your energy bill. Try to use the temperatures in the chart above. For every degree you set your thermostat higher in summer or lower in winter, you can save about 3% on your energy costs.

end of the day. "NHT" may be the time you go to sleep — another time to save money on your utility bill. You can change these times and settings any way you like, or even use the same setting most of the time, to suit your lifestyle.

Time, Temperature And Batteries

If you set the thermostat for 78 degrees at 8:00 a.m., the thermostat automatically calculates how much time it needs to start heating or cooling **before** 8:00 am, so that at exactly 8:00 am, it will be 78 degrees.


Step 1: Set The Current Time And Day

Press the TIME (Ⓝ) button once. The hour will appear. Press and hold the up or down arrow until you reach the correct hour and AM/PM setting. Press TIME again. Set the minutes in the same way. Press TIME again to set the day of the week. When you have selected all of the correct time settings, press the RUN (Ⓟ) button once.

Cooling & Heating Schedule Plan						
PERIOD	WEEKDAYS (5-DAY)		SATURDAY (1-DAY)		SUNDAY (1-DAY)	
	Start Time	Temp	Start Time	Temp	Start Time	Temp
COOL	MOR					
	DAY					
	EVE					
	NHT					
HEAT	MOR					
	DAY					
	EVE					
	NHT					

Step 2: Set The Cooling Program

1. Press the SYSTEM (Ⓢ) button until "COOL" is displayed.
2. Press the PROGRAM (Ⓟ) button. The word "MOR" will appear in the upper left corner. This corresponds with the word "MOR" on the programming chart. On the right are the days (Monday – Friday), a time and a temperature. The temperature should be blinking. Use the up or down arrow to change the temperature to the setting you wrote on your chart.
3. Press TIME (Ⓝ) to set the time of your first cooling period. When you press PROGRAM again, it will change to the second time on your chart: "DAY." Pick the temperature and time, repeating steps 2 – 3 until you have programmed all of the times on your chart through Sunday evening.
4. Press the RUN (Ⓟ) button.



Step 3: Set The Heating Program

1. Press the SYSTEM (Ⓢ) button until "HEAT" is displayed.
2. Press the PROGRAM (Ⓟ) button. Set the temperature, then the time for the first heating period of the day by repeating the steps 2 - 4 above.

Step 4: Remove The Batteries

White-Rodgers has discovered that there is a small chance these thermostat batteries may leak and potentially overheat, resulting in a potential safety problem. If batteries are in your thermostat, you can remove them easily using the instructions outlined at www.austinenergy.com/go/thermostatnotice.

If you make a mistake, just press the RUN (Ⓟ) button and go back through the steps, changing the settings as needed, pressing PROGRAM (Ⓟ) to speed through them.

Who Do I Call For Help?

You can call Austin Energy's Thermostat program toll free at **1-877-549-2774**. You can also check Austin Energy's Web site www.austinenergy.com for a more detailed programming guide.

